



TRENCHERS

Part Number	Model(s)	Kit Type
190-2177	410SX (GAS)	1000HR
190-2200	C12	Basic
190-2426	C14	Basic
190-2430	C16/C16X	Basic
190-2435	C24X	Basic
190-2440	C30X	Basic
190-1759	RT12	Basic
190-1760	RT16	Basic
190-1761	RT20/24	Basic
190-1764	RT45	Basic
190-1766	410SX T4i	Basic
190-1767	420SX T2/T4i	Basic
190-2103	RT30	Basic
190-2122	RT80Q T4F	1000 HR
190-2142	RT120 T4i	1000 HR
190-2147	RT100 T4i	1000 HR
190-2151	RT45 T4F	1000 HR
190-2152	RT45 T4i	1000 HR
190-2154	RT45 T4i	Basic
190-2166	RT120Q T4i	1000 HR
190-2176	410SX GAS	1000 HR
190-2181	RT55 T4i	1000 HR
190-2151	RT45 T4F	1000 HR
190-2153	RT45 T4	Basic
190-2197	ST37X	Basic
190-2167	RT125 QUAD	Basic

MINI SKID STEERS

Part Number	Model(s)	Kit Type
190-1762	SK350	Basic
190-1763	SK650/SK750/SK752/SK755 T4i	Basic
190-2196	SK850/SK1050/SK1550	Basic
190-1765	R300	Basic
190-2195	SK600/SK800	Basic

TRENCHLESS

Part Number	Model(s)	Kit Type
190-2100	FM25	Basic
190-2105	FM13V	Basic
190-2131	JT5 T4F	1000 HR
190-2172	JT9 T4F	1000 HR
190-2174	JT9 T4i	1000 HR
190-2112	JT20 T4F/T4i	1000 HR
190-2106	JT25 T3	1000 HR
190-2107	JT25 T4i	1000 HR
190-2136	JT/AT30 T3	1000 HR
190-2137	JT/AT30 T4i	1000 HR
190-2116	JT/AT100 T3	1000 HR
190-2126	JT1220 T4i	1000 HR
190-2173	JT922 T3	1000 HR
190-2191	MR90	1000 HR
190-2156	JT/AT60 T3	1000 HR
190-2445	JT/AT40 HRC	Basic
190-2447	JT/AT40 LRC	Basic
190-2117	JT/AT100 T4F	Basic
190-1052	AT30 T3	Basic
190-2138	JT25/JT30/AT30 T4F	Basic
190-2139	JT25/JT30/AT30 LRC	1000 HR

VACUUM EXCAVATORS

Part Number	Model(s)	Kit Type
190-2101	FX20	Basic
190-2102	FX25/MV800	Basic
190-2104	FX30/FXT30 T3/T4F (NOT T4i)	1000 HR
190-2161	FX50/FXT50 T4i	1000 HR
190-2162	FX50/FXT50 T4F	1000 HR
190-2186	FX60 T4i	1000 HR
190-2187	FX60/FXT60/FX65/FXT65 T4	1000 HR